


CookerSafe

Electrical Safety Device to safeguard your assets, tenants and property.

Ideal For



Install CookerSafe to Reduce FIRE RISK

Protect Life & Assets

CE Approved

Built from Fire Retardant Plasticiser rated to UL94V-0

Control Unit 86 x 86 x 25.5mm

Head Office

Pace Systems
PO Box 7088
Walsall
WS9 1ED

Tel: +44 (0) 800 088 5861
www.pace-systems.co.uk



info@pace-systems.co.uk

Device colour & layout could be subject to change.

CookerSafe

Electrical Safety Device to safeguard your assets, tenants and property.

CookerSafe offers the following safety features:

- Provides a robust cut-off switch that stops the mains power supply to the cooker. CookerSafe offers controlled power delivery via a display timer and can only operate with manual intervention.
- Easy operation via the control button, press once to set the timer to 15 minutes, or press twice for 30 minutes. To turn the cooker off completely during the cooking cycle, simply press and hold the control button for 5 seconds.
- If further cooking time is required after 30 minutes, the control button can be used again. CookerSafe means that the cooker is never left unattended for longer than 30 minutes.
- CookerSafe will control two devices, electric oven & electric hob.
- Can be installed by a qualified electrician to existing appliances or installed as part of a new build/renovation.



More fires and fire injuries are caused in the kitchen than anywhere else in the home.

Around 60% of accidental fires in the home start in the kitchen.*

London Fire Brigade recommend never leaving cooking unattended and that you don't cook if you::

- Are tired
- Have been drinking alcohol
- Are taking medication that might make you drowsy

info@pace-systems.co.uk

Head Office

Pace Systems
PO Box 7088
Walsall
WS9 1ED

Tel: +44 (0) 800 088 5861
www.pace-systems.co.uk



* Information taken from the London Fire Brigade website: <http://www.london-fire.gov.uk/SafetyInTheKitchen.asp>